



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

RENAULT

MOD.

CLIO*

YEAR.

01 →

PETROL
DIESEL



* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the wheel house, passenger's side.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+ **30**: connect to the RED wire, at the position A3, in the P202 connector, under the dashboard, driver's side.
- **31**: connect to the BLACK wire, at the position A4, in the P202 connector, under the dashboard, driver's side.

IGNITION WIRE

+ **15/54**: connect to the YELLOW /VIOLET wire, at the position A4, in the 15 way P202 white connector located in the central under the dashboard, driver's side.

DIRECTION INDICATORS

Connect to the WHITE/BROWN wire, at the position A3 and to the LIGHT VIOLET/BROWN wire, at the position A2, in the 15 way P203 black connector, in the central placed under the dashboard, driver's side.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the LIGHT VIOLET wire, at the position B5, in a 15 way white connector, in the central placed under the dashboard, driver's side.

Front window, passenger's side:

cut the WHITE/ORANGE wire in the bundle of cables coming out of the driver's side door.

ACTIVAT./DEACTIVATION CONTROLS

Connections antitheft/vehicle

Art.38XX	Vehicle	Position
GREY/BLACK	WHITE	Position B8 black connector.
YELLOW/BLACK	GREEN	Position B4 black connector.
ORANGE/WHITE	+30	In the fuse box.
ORANGE	+30	In the fuse box.
VIOLET	PINK	Position B1 serial switch.
VIOLET/WHITE	Ground	Car body.

The above mentioned black connector is located behind the left lateral bulkhead, near the switch lever.

Refer to the **B diagram** specified in the dedicated installation manual enclosed in the kit of the antitheft.

IMMOBILISATION POINT

Fuel pump

Cut the LIGHT BROWN wire, at the position A2, in the 26 way black connector, fixed behind the driver's side bulkhead.

STARTER

+**50**: Cut the ORANGE wire located on the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support plate, driver's side.

FRONT DOORS SWITCH

Connect to the GREEN wire, at the position nr. 40, in the 40 way black connector, in the central under the dashboard driver's side.

REAR DOORS SWITCH

Connect to the GREY wire, at the position nr. 30, in the 40 way black connector, in the central under the dashboard driver's side.

BOOT SWITCH

Connect to the GREEN wire, at the position nr. 39, in the 40 way black connector, in the central under the dashboard driver's side.