

# LIST OF CONNECTIONS

CONNECTION CODES	CONNECTION TITLES
R2	DASHBOARD/LEFT REAR CONNECTION
R3	DASHBOARD/DRIVER'S DOOR CONNECTION
R4	DASHBOARD/PASSENGER'S DOOR CONNECTION
R13	LEFT REAR/LEFT-HAND REAR DOOR CONNECTION
R15	LEFT REAR/LEFT-HAND TAILGATE CONNECTION
R35	PEDAL ASSEMBLY/DASHBOARD CONNECTION
R37	ENGINE/INJECTION CONNECTION
R67	FRONT OF ENGINE/ENGINE CONNECTION
R99	DASHBOARD/HEATING CONNECTION
R101	RIGHT-HAND SIDE MEMBER/RIGHT-HAND HEADLIGHT CONNECTION
R106	FRONT OF ENGINE/BUMPER CONNECTION
R107	DASHBOARD/FRONT OF ENGINE CONNECTION
R112	FRONT OF ENGINE/BODYWORK CONNECTION
R179	ANTI-LOCK BRAKING SYSTEM/LEFT-HAND FRONT WING CONNECTION
R187	PASSENGER COMPARTMENT/CENTRAL COURTESY LIGHT CONNECTION
R235	DASHBOARD/AUTOMATIC GEARBOX CONNECTION
R243	RIGHT-HAND REAR DOOR/REAR LEFT-HAND WIRING CONNECTION
R255	ANTI-LOCK BRAKING SYSTEM/WATER BOX CONNECTION
R260	PASSENGER COMPARTMENT/LEFT-HAND ROOF CONNECTION
R277	PASSENGER COMPARTMENT/DRIVER'S PRETENSIONER CONNECTION
R278	PASSENGER COMPARTMENT/PASSENGER PRETENSIONER CONNECTION
R296	PASSENGER COMPARTMENT/REAR RIGHT CONNECTION
R297	PASSENGER COMPARTMENT/REAR LEFT CONNECTION
R301	DASHBOARD/COURTESY LIGHT CONNECTION
R318	DASHBOARD/STEERING COLUMN CONNECTION